

HOSE REEL

REMOTE GUIDE



B BAZOOKA
FARMSTAR

QUICK REF GUIDE

Brake Tension (+) More Tension

- There are 7 brake tension settings
- Only active when in Freewheel Mode.

Brake Tension (-) Less Tension

- Lowest brake tension setting turns brake off for true freewheel.
- Only active when in Freewheel Mode.

Speed (+) Faster (3 speed settings)

- Higher speed = lower torque

Speed (-) Slower (3 speed settings)

- Lower speed = higher torque



QUICK REF GUIDE

Off – Stops reel and engages locks. Do not turn off tractor hydraulics when trying to stop reel or it may not stop quickly.

Freewheel – Activates freewheel mode and the ability to increase or decrease brake tension when unwinding hose.

HYDRAULICS MUST BE ON!!

Unwind – Activates “Power Unwind” mode to hydraulically unwind the reel, and the ability to choose your unwind speed.

Wind – Activates “Power Wind” mode to hydraulically wind in hose, and the ability to choose your wind speed.